

# ADAPTADORES DE LA CULATA

Destinado para su uso con taladros Atlas Copco

PARTE #	ROCK DRILL	HILO	LARGO	SUPERFICIE DE IMPACTO	CABEZA FRONTAL	ALETA
			MM	MM	MM	MM
450853	COP 1132	R32	410	25	35	79
450914	COP 1132	R35	410	25	35	79
450854	COP 1132	R32	500	25	35	80
450089	COP 1032	R32F	340	34	45	59
450094	COP 1238ME	R32	575	34	38	74
450284	COP 1238ME	HM38	575	34	38	74
450150	COP 1238ME	R38	476	34	38	74
450286	COP 1238ME	HM38	476	34	38	74
450423	COP 1238ME	R38	486	34	38	74

# ADAPTADORES DE LA CULATA

Destinado para su uso con taladros Atlas Copco

PARTE #	ROCK DRILL	HILO	LARGO	SUPERFICIE DE IMPACTO	CABEZA FRONTAL	ALETA
			MM	MM	MM	MM
450092	COP 1238ME	R32	500	34	38	74
450282	COP 1238ME	HM38	500	34	38	74
450632	COP 1238ME	HM45	575	34	45	74
450889	COP 1838	HM38	525	34	52	84
450713	COP 1838ME	HM45	525	34	52	84
450539	COP 1838ME	HM51	525	34	52	84
450605	COP 1838ME	HM38	730	34	60	116
450607	COP 1838ME	HM45	730	34	60	116
450857	COP 1838MU	HM38	730	34	52	124
450856	COP 1838MU	HM45	730	34	52	124

# ADAPTADORES DE LA CULATA

Destinado para su uso con taladros Atlas Copco

PARTE #	ROCK DRILL	HILO	LARGO	SUPERFICIE DE IMPACTO	CABEZA FRONTAL	ALETA
			MM	MM	MM	MM



450614	COP 1838T	R32	435	36	38	84
450631	COP 1838T	R32	525	36	38	84
450469	COP 1838T	R38	435	36	38	84
450550	COP 1838T	HM38	435	36	38	84
450551	COP 1838T	HM38	525	36	38	84



450548	COP 1840ME	HM45	565	35	52	126
450634	COP 1840ME	HM51	565	35	52	126



450858	COP 2160	HM51	770	37	63	156
--------	----------	------	-----	----	----	-----



450916	COP 3060	BE58	745	50	90	144
--------	----------	------	-----	----	----	-----



450863	COP 4050	BE58	834	46	90	134
450826	COP 4050	BE68	834	46	90	134



450878	COP 4050	EL60	700	52	70	109
--------	----------	------	-----	----	----	-----

# ADAPTADORES DE LA CULATA

Destinado para su uso con taladros Atlas Copco

PARTE #	ROCK DRILL	HILO	LARGO	SUPERFICIE DE IMPACTO	CABEZA FRONTAL	ALETA
			MM	MM	MM	MM
450909	COP 4050	BE58	834	46	90	113

